







Thule Rapid System Kit 1792

> Instructions

HONDA HR-V, 5-dr SUV, 15- / 16-*

HONDA Vezel, 5-dr SUV, 14-

*North America




ISO 11154-E

141792
C.20160119
519-1792-02


Bring your life
thule.com




204 x1




206 x1



370 x1



371 x1



1366 x2



1367 x2






x1



x1

1

	X (scale)	X (mm)	X (inch)
HONDA HR-V , 5-dr SUV, 15- / 16-*	40	1051	41 ³ / ₈
HONDA Vezel , 5-dr SUV, 14-	40	1051	41 ³ / ₈





	Y (scale)	Y (mm)	Y (inch)
HONDA HR-V , 5-dr SUV, 15- / 16-*	38	1031	40 ⁵ / ₈
HONDA Vezel , 5-dr SUV, 14-	38	1031	40 ⁵ / ₈


2

HONDA HR-V, 5-dr SUV, 15- / 16-*

HONDA Vezel, 5-dr SUV, 14-



3



	W (mm)	Z (mm)	W (inch)	Z (inch)
HONDA HR-V , 5-dr SUV, 15- / 16-*	270	620	10 5/8	24 3/8
HONDA Vezel , 5-dr SUV, 14-	270	620	10 5/8	24 3/8

